



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6G255501	Drag Knob	37	6G404701	Bail Trip Lever
2	6E134508	Screw (A)	38	6G194301	Brake Shoe
3	6G464401	Plate	39	63753000	Washer (D)
4	6G464301	Drag seat	40	6G193701	Screw (G)
5	6F094901	Key Washer	41	6G332701	Screw (H)
6	6G464201	Eared Washer	42	6G229901	Bearing Retainer
7	63733603	Drag Washer	43	6G482001	Ball Bearing (B)
2-11	6G633701	Spool Assembly	44	6F920602	Collar (B)
2-11	6G633701	Spool Assembly (Extra Spool)	45	6F641501	Clutch Cam Retainer
9	6B075304	Click Pawl	46	6F641401	Clutch Cam
10	6G366501	Click Spring	47	63737814	Washer (E)
11	63205901	Click Retainer	48	6F732203	Spacing Sleeve
12	6F094701	Washer (A)	49	6G314501	Roller Clutch
13	6E462701	Click Gear	50	6G472701	Ball Bearing (C)
14	6G465001	Main Shaft	51	63737814	Washer (F)
15	6G025501	Oscillating Slider	52	6G291301	Pinion Gear
16	63521505	Screw (B)	53	6G633401	Body
17	6G123301	Rotor Nut	54	6G193103	Anti-Reverse Lever
18	6G404506	Rotor	55	6G193301	Anti-Reverse Cam Spring
19	6G195601	Screw (C)	56	6F131601	Collar (C)
20	6G194501	Bail Arm	57	6G131700	Washer (G)
21	6G224901	Screw (D)	58	6F747801	Oscillating Gear
22	6F897101	Washer (B)	59	6G230106	Rear Cover
23	6G281601	Ball Bearing (A)	60	6G256401	Washer (H)
24	6G461301	Line Roller	61	6G400101	Screw (I)
25	6G047601	Collar (A)	62	6E154001	Ball Bearing (D)
26	6G405101	Bail Assembly	63	6G025601	Drive Gear
27	63516101	Screw (E)	64	63737800	Washer (I)
28	6G017502	Bail Spring Shaft	65	66316901	Ball Bearing (E)
29	6G148601	Bail Spring	66	6G462902	Side Cover
30	6G017401	Bail Spring Holder	67	6G332902	Screw (J)
31	6G405004	Cover (A)	68	6G333002	Screw (K)
32	6G256401	Washer (C)	69	6G633501	Handle Assembly
33	6G205101	Screw (F)	70	6F721201	Collar (D)
34	6G484501	Cover (B)	71	61608101	Washer (J)
35	6G195101	Bail Holder Nut	72	6F425808	Screw (L)
36	6G404601	Bail Trip Lever Spring			